3 Single Coils 1 Volume 2 Tones **BECOS Micro Booster Bridge** Tone Center Installation Wiring Diagram Neck Tone 250K 250K Drawing by BECOS www.becos.ro Neck Signal through Booster Volume **DOWN** 250K Signal True By-Pass to Output **Pickup Switch** Middle ©G Ctone IN (**uBST Bridge GROUND Output** Jack RING When instrument cable is inserted, Ring to Ground powers Booster circuit.